



Таблица за преобразуване на инчове в милиметри

inch		mm		
–	1/32	2/64	0,03125	0,79
1/16	2/32	4/64	0,0625	1,59
–	3/32	6/64	0,09375	2,38
1/8	4/32	8/64	0,125	3,18
–	5/32	10/64	0,15625	3,97
3/16	6/32	12/64	0,1875	4,76
–	7/32	14/64	0,21875	5,56
1/4	8/32	16/64	0,250	6,35
–	9/32	18/64	0,28125	7,14
5/16	10/32	20/64	0,3125	7,94
–	11/32	22/64	0,34375	8,73
3/8	12/32	24/64	0,375	9,53
–	13/32	26/64	0,40625	10,32
7/16	14/32	28/64	0,4375	11,11
–	15/32	30/64	0,46875	11,91
1/2	16/32	32/64	0,500	12,70
–	17/32	34/64	0,53125	13,49
9/16	18/32	36/64	0,5625	14,29
–	19/32	38/64	0,59375	15,08
5/8	20/32	40/64	0,625	15,88
–	21/32	42/64	0,65625	16,67
11/16	22/32	44/64	0,6875	17,46
–	23/32	46/64	0,71875	18,26



3/4	24/32	48/64	0,750	19,05
–	25/32	50/64	0,78125	19,84
13/16	36/32	52/64	0,8125	20,64
–	27/32	54/64	0,84375	21,43
7/8	28/32	56/64	0,875	22,23
–	29/32	58/64	0,90625	23,02
15/16	30/32	60/64	0,9375	23,81
–	31/32	62/64	0,96875	24,61
16/16	32/32	64/64	1,000	25,40